



Outside

- Note any obstacles that could cause damage
- Locate utility hook ups
- Check AC shore power
- Safely park in any spot that is relatively level and where the ground is firm.
- When boondocking, use GPS to determine location in case of emergency
- Use the stabilizing jacks to securely contact the ground
- Release hitch and coupler if you plan on using your vehicle
- Remove safety chains and breakaway switch cable.
- Dismount towing mirrors
- Fully extend hitch jack; install puck
- Connect water
- Connect electricity
- Ensure LP tank valve is open
- Ensure that master battery disconnect switch is "ON"
- Turn on the LPG
- Pull out step
- Unlock the main door
- Extend your awning
- Set up TV antenna
- Set up solar panels
- Note mileage and fuel level

Inside

- Turn on water heater
- Open vents/windows
- Set HVAC
- Turn on refrigerator
- Check for items that have shuffled out of place during travel
- Set up tables and bedding
- Set up décor